

Important – Read instruction before use Care & Safety Instructions and manual

Hanukkah Menorah 3⁹



Opening the packaging and inspection:

- Remove the concrete Menorah from her packaging and place it on a level, stable surface.
- **Store the candles in a cool, shaded place. Do not leave the candle exposed to heat and sunlight before and after use.**

Candle preparation and lighting:

- Right before using the candle, **place the concrete Menorah on a leveled, stable surface**, far from the reach of children, far from loose object that may move near the Menorah (branches, curtains, etc.) and away from any flammable materials and elements.
- Before placing the candles, turn the candle bases upon the desirable shape, to the front, rear or up sides, facing the candle holes straight up.
- Hold the Menorah and carefully place the candles in the holes center (fit most candles with 7-9 mm diameter) of the concrete Menorah, light them carefully.
- **The Menorah must not be move when the candles are lit and after the candles are extinguished, wait for the wax to cool before moving.**
- **Never leave a burning candle unattended**
- Clean candles wax with hot water.
- It's recommended to align the bases to one direction and lay the Menorah down.

חשוב – לפני כל שימוש

יש לקרוא את הוראות הבטיחות והשימוש ולפעול בהתאם



חנוכיית 3⁹

פתיחת האריזה ובדיקה מקדימה:

- להוציא את בסיסי הבטון מאריזתם ולהניחם על משטח ישר ויציב
- **יש לאחסן את הנרות במקום קריר ומוצל. אין להשאיר את הנרות במקום חשוף לחום ולשמש, לפני ואחרי השימוש בהם.**

הכנה והדלקת החנוכייה:

- קרוב למועד השימוש בחנוכייה, **מציבים אותה על משטח ישר ויציב**, רחוק מהישג ידם של ילדים, רחוק מסכנת פגיעה ע"י גורמים שעשויים לנוע ולפגוע בפמוט (ענפים, וילונות וכו') **והרחק מכל גורם דליק.**
- לפני התקנת הנרות, מסובבים את בסיסי הבטון קדימה, למעלה או לאחור לקבלת הצורה המבוקשת ומייצבים כך ששקעי הנרות בכל פאה יהיו ישרים כלפי מעלה. אין להפעיל כח רב ויש להימנע מפגיעת הבסיסים במשטח או באובייקטים קשים ושבירתם.
- שקעי הנרות מתאימים לרוב סוגי הנרות עם בסיס בקוטר 7-9 מ"מ, מחזיקים את החנוכייה ומכניסים ישר את הנרות במרכז השקע.
- מדליקים את הנרות בזהירות, בלי לקרב את היד ללהבת הנר.
- **אסור להזיז את החנוכייה כאשר הנרות דולקים וגם לאחר כיבוי הנרות, יש להמתין עד להתקרשות השעווה בטרם הזזתם.**
- **אין להשאיר נרות דולקים ללא השגחה.**
- ניתן לנקות את החנוכייה משעווה עם מים חמים.
- בתום כל שימוש מומלץ ליישר את כל הבסיסים לאותו כיוון ולהשכיבם.